



Installation Instructions

Tools Required For Installation:

Plastic Squeegee, Fine Tip Marker, Utility Knife/Hobby Knife, Tape Measure, Fine Mist Sprayer Bottle, Scissors, Cloth

How To Apply Your Window Film:

- Measure the window glass size and cut the film to approximately 1 inch (2.5cm) larger than the size you measured.
- Clean the glass thoroughly. Make sure the glass is completely clean and free of all dust, dirt and debris. **A clean surface is necessary for getting a smooth finish without any bubbles and to ensure the film does not come off over time.**
- Gently peel off the clear film backing. Ensure to not accidentally fold or crease the film while doing so. **The side that goes against the glass is the side the clear film backing was peeled off from.**
- Using a fine mist spray bottle, spray both the glass and the back of the window film with clean water. Ensure to get complete coverage with a light mist.
- Place the film and line it up on the window. Gently use a squeegee to smooth out the film and to remove air bubbles. Use cloth to wipe up any excess water.
- Using a utility knife or hobby knife, trim off the excess that overhangs ensuring that the film is on the glass and no parts rest against the side framing of the window.